



NOTE:
 IN SUB FLOOR AREAS THE TEMPORARY SUPPORT MUST EITHER:
 - BE REMOVED 28 DAYS AFTER THE CONCRETE POUR OR
 - HAVE A DPC BARRIER BETWEEN THE TIMBER AND FLATDECK SHEET.

Original Size A4

| | |
|---------------------|--------------------------------------|
| Issue: 01 | Reference dim_drv_fdk_1080 |
| Scale: 1 : 5 | |
| Date: 18 March 2019 | |