



NOTE:
 IN SUB FLOOR AREAS THE TEMPORARY SUPPORT MUST EITHER:
 - BE REMOVED 28 DAYS AFTER THE CONCRETE POUR OR
 - HAVE A DPC BARRIER BETWEEN THE TIMBER AND FLATDECK SHEET.

Original Size A4



Hibond 55

Dimond Hibond 55 Flooring System Detail

Block Timber Wall

Issue: 01	Reference dim_drv_h55_1110
Scale: 1 : 5	
Date: 18 March 2019	