



Note:
 In sub floor areas the temporary support must either:
 -Be removed 28 days after concrete pour or
 -Have a DPC barrier between the timber and HiBond sheet.

Original Size A4

Issue: 01	Reference dim_drv_h80_1140
Scale: 1 : 5	
Date: 18 March 2019	