



Note: The flow control should be inserted with the protruding side into the showerhead, taking care not to cause any damage to the flow controller. In accordance with AS/NZS3662 Cl.6e.

These showers may not be suitable for use with gravity fed water heaters, low and unequal pressure supply networks, instantaneous water heaters, tempering valves and/or thermostatic mixing valves. in accordance with AS/NZS3662Cl.6c.

The following pressure range should be complied with:

- Minimum working pressure 150Kpa
- Maximum working pressure 750Kpa

ALL ABEY SHOWERS MUST BE INSTALLED IN ACCORDANCE WITH AS/NZS3500 SERIES.