


**⚠ CAUTION** Light Fitting Must Be Installed By A Licensed Electrician

Please ensure to read instructions correctly for the installation of the fitting provided. Failure to do so will result in a void of warranty and compromises the safety of luminaire.


FAZE are not liable for warranties when luminaire is damaged by incorrect installation. The installation of the luminaires must be in accordance with the national safety regulations.

Please refer to FAZE's General Terms & Conditions for more information concerning the installation and warranty of our products.


**Installation Instructions**




Take off the head, and unscrew the cover.



Connect the AC wire. Drill screw holes, and install base to surface.



Re-install the cover.



Re-install the head with the fast connector.

|          |       |          |                         |           |     |
|----------|-------|----------|-------------------------|-----------|-----|
| LED      | 9W x2 | Warranty | 5 Years                 | CRI       | 95+ |
| Category | Wall  | Material | Powder Coated Aluminium | IP Rating | 20  |



For warranty information please visit [fazelight.com](http://fazelight.com)  
For all other queries, please call us on 1300 438 609