

GARMEN PENOPTICS – FORWARD VIEW SET UP

KEY

Prior to starting I did a “[Restore Sonar Defaults](#)” on my Garmin as per the Installation page below.

The fields with a yellow background have the same name as the screens that make up the Garmin perspective mode set up. On your Garmin device click on >> to open the linked pages.

The fields shown in red fonts are the changes I made to the factory settings.

The other fields still in black are as per the factory settings.

Live Scope Forward Menu						
Gain		< 8 meters = 90% > 8 Meters 60-70%				
Depth Range		20m				
Forward Range		5m				
Pause Sonar						
Transmit		On				
Sonar Setup >>	Sonar Setup		Appearance >>		Sonar Appearance	
					Color scheme	I like Black emerald or Amber
					Color gain	61%
					Color limit	64%
					Trails	Off
					Bottom Fill	On
			Layout >>		Sonar Layout	
					Grid overlay	Show
					Scroll History	Hide
			Noise Reject	High	On screen Control	Show
			TVG	Off	Reverse Range	Default
			Ghost Reject	Off	Compass Range	Off
			Overlay data >>		Sonar Overlay	
					Device Voltage	Show
					Depth	Show
					Speed	Show
					Water Temperature	Auto
					Time	Show
Edit Overlays >>	Edit Overlays					
	Navigation Insert	Auto				
	Top Bar	Compass Tape				
	Bottom Bar	Compass Tape				
		Installation >>				
					Installation	
					Install Depth	0.3m
					Use AHRS	Off
					Flipped	Off
					Pitch Angle	36 degrees
					Orientation	Forward
					Focus	Auto Fresh
					Restore Sonar Defaults	

GARMEN PENOPTICS – FORWARD VIEW SET UP

KEY

Prior to starting I did a “[Restore Sonar Defaults](#)” on my Garmin as per the Installation page below.

The fields with a yellow background have the same name as the screens that make up the Garmin perspective mode set up. On your Garmin device click on >> to open the linked pages.

The fields shown in red fonts are the changes I made to the factory settings.

The other fields still in black are as per the factory settings.