

## Installation Manual




### Notes

1. Product must be installed in accordance with the current regulations and electrical codes of Australia and all wiring must be done by a qualified electrician.
2. These products are designed for connection to a 180-305V AC 50/60Hz supply.
3. Any broken or damaged parts should be replaced as soon as possible.
4. Always disconnect power before installation or servicing.
5. Mondolux will not accept responsibility for any claims arising from a poor installation.

### Installation Steps

1. Ensure the mains power is turned off.
2. Cut required holes in ceiling. Ensure minimum space requirements between fitting and driver. See picture 1.
3. Pass the driver power supply wires through the cutout and plug into mains socket.
4. Connect the driver to the light fitting using the quick connector. See picture 2.
5. Mount fixture into ceiling and secure using the spring loaded clips.
6. Adjust the lamp angle to suit required illumination need. See picture 3.
7. Installation is complete.



### Wiring Instructions

180 - 305VAC 50/60Hz / Class I

Note: Class I products must always be Earthed/Grounded




Fig.1




Fig.2




Fig.3

