


Installation Manual



Notes

- This fitting requires 220-240V AC/50Hz power input to the driver.
- Do not interchange any parts of this fitting.
- Allow a minimum distance between fitting and illuminated subject of 800mm.
- Do not touch fitting when in use.
- Do not install fitting near any heat source.
- Do not install any inductive loads such as exhaust fans etc. within the same lighting circuit of the current fitting. Issues caused by such connections will not be covered under our warranty policy.
- If you have any questions about the installation of this product, please contact Mondolux.



Installation Steps

1. Ensure the mains power is turned off.
2. Drill required number of holes in the ceiling and fix the mounting plate using the provided screws. See picture 2.
3. Pass the power supply cable through the center of the mounting plate and secure it using the cable grip provided. See picture 3.
4. Connect the L, N and E wires on the supply side to the respective terminals of the driver using quick connectors. See picture 4.
5. Fit and rotate to fix the fitting to the mounting plate. See picture 3 and 4.
6. Installation is complete. See picture 5.

