



Product specification sheet, product accessories

Product specification sheet:

Product model	Nominal voltage	Rated frequency	Rated power	Rated capacity	Suitable number of people
GS-HDC20X	220V~	50Hz	200W	1.2L	1-2 人


Product accessories


Ladle

Measuring glass

A steamer or dish

Power line





Special statement:

All contents in this material have been carefully checked. In case of product technology or software upgrade, it will be incorporated into the new edition of the manual. If there is any change in the appearance, color and performance of the product, the material object shall prevail.

### Usage of products

#### Method of application

● Use a cup to measure rice (a cup of rice is about 100mL~ 160mL). In order to protect the coating of the inner pot, please do not use the inner pot to wash rice.



● For example, a 1.2L rice cooker can cook up to 2 cups of rice. If it exceeds the limit, the rice is not cooked or overflows.

- Put the scoured rice into the inner pot, and select the water level according to the required rice quantity
- Put the inner pot into the pot body and close the upper cover.
- In order to make the bottom of the pot and the heating plate fit closely, please put the inner pot in and turn it left and right for 2-3 times.
- Plug in the power plug. Please confirm whether the plug of the cooker body and the power plug have been inserted in place, and stand by after powering on, displaying "-"
- Press the function key to select the required function, and then press Start to enter the working state, or press the corresponding function key to directly enter the working state.

## **I. Electrical performance**

1. Rated working voltage: 220 VAC (50Hz/60Hz)
2. Sensor: lower sensor 50K

## **II. Environment**

1. Working environment: temperature-20 °C ~+80 °C, relative humidity below 95%KH
2. Storage environment: temperature-40°C ~+105 °C, relative humidity below 95%KH

## **III. Control Output Parameters and Description**

1. Power-on procedure:  
Power-on state: After full display for 1S, "DI" sounds to enter standby, and it displays "00".
2. General description of functions:
  1. It has the functions of double-gallbladder sugar-removing rice, porridge cooking, single-gallbladder cooking, and heat preservation;
  2. Reservation function;
  3. Sensor open and short circuit protection;

### 3. Setting of each key function:

#### 1. "reservation" key

Press the reservation key to select the reservation time, and then select the corresponding function lamp to flash, and the display screen flashes to display the time. After 5 flashes, the reservation function will be entered, with the default value of 0.5 hours.

Appointment range: 0.5 hours to 24 hours. It is invalid to press this key during work. Press the reservation key when selecting functions to adjust the reservation time, and each time you press it, it will increase by 0.5 hours.

#### 2. "Function selection" key:

Effective in non-working state, select functions;

#### 3. "Insulation/Cancel" key:

Select function not started, function started and standby state and press this key to enter the heat preservation mode. Press this button to enter the standby state while keeping warm.

#### 4. Cooking interface time display setting and process Double gallbladder sugar-removing rice:

Select this function, and the corresponding function lamp flashes. The display screen flashes and shows that the default time is "30". After the function is started, the corresponding function lamp stays on, and the display screen shows PO "0" dynamic display. After the hot pot is turned on, the countdown lasts for 30 minutes, and the buzzer sounds 3 times to enter the heat preservation state.

#### 5. Cook porridge:

Select this function, and the corresponding function lights will flash, and the display screen will flash for "1.5" hours. After the function is started, the corresponding function lights will always light up, and the display screen will start counting down, and the buzzer will ring 3 times to enter the heat preservation state.

#### 6. Cooking with one gallbladder:

Select this function, and the corresponding function lamp flashes, and the display screen flashes to show that the default time is "12". After the function is started, the

corresponding function lamp is always on, and the display screen shows PO "0" dynamic display. After the meal is cooked, the countdown lasts for 12 minutes, and the buzzer sounds 3 times to enter the heat preservation state.

#### 7. Appointment:

Select the corresponding function and press the reservation key to select the reservation time. The corresponding function lamp flashes, and the display screen flashes to show that the time flashes 5 times to enter the reservation function. The default reservation time is "0.5", the reservation lamp lights up, and the time can be adjusted within the range of "0.5~24". After the reservation time is completed, the menu function is entered.

#### 8. Heat preservation:

It is displayed as "bb" by default. After the function is started, the heat preservation function lamp, heat preservation/cancellation lamp and start lamp are always on. The longest heat preservation time is 24 hours. After heat preservation, it enters the standby state.

#### 9. Steamed vegetables:

Select steamed vegetable function application function. The corresponding function lamp flashes, and the display screen flashes. The default time is 25. After the function is started, the corresponding function lamp stays on. The display screen displays 25. The dynamic display shows that the countdown is 25 minutes after the food is cooked. The countdown ends. The buzzer sounds 3 times and enters the heat preservation state.

### **Product view**

#### Safety matters

In order to make you use this product safely and correctly, please observe the precautions for product safety listed below.

1. Please do not disassemble or repair this product by yourself. When you need to repair products, please contact the repair outlets designated by our company.
2. It is forbidden to place the rice cooker beside inflammable and explosive articles and use it in damp environment.
3. Please plug the power cord into the body socket and the power socket, and make sure it is completely inserted. Otherwise, it may cause electric shock, short circuit and even fire accident.

4. Do not let children operate alone or put them in places where children can reach them, so as to avoid accidents such as electric shock and scald of children.
5. Do not move the rice cooker while working. When moving the rice cooker, make sure that the power cord of the product is unplugged.
6. Please unplug the power cord from the power outlet when not in use.
7. Please do not cover the exhaust port with cloth during work, and do not put other objects on the pot body. So as not to damage the rice cooker or cause an accident.
8. Please do not open the cooker cover during work. Please pull out the power plug or disconnect the power supply after work.
9. During or shortly after work, do not touch high temperature parts, such as inner cover, exhaust port, inner pot or heating plate.
10. Do not use the inner pot directly on open flames or other heating equipment. Otherwise, the inner pot may be deformed.
11. Before cooking rice, please install the anti-overflow steam valve correctly on the upper cover, so as to avoid accidents caused by scalding and damaging the rice cooker.
12. When cleaning the rice cooker, please pull out the power plug first. Do not immerse the rice cooker in water.
13. The normal working altitude of the product ranges from 0 to 2000 meters.
14. If the power cord is damaged, it must be replaced with a special cord or a special component purchased from its manufacturer or maintenance department.

## **Matters needing attention and cleaning methods**

### **Matters need attention**

1. The inner pot cannot be heated on other stoves, otherwise it is easy to deform.
2. When the rice starts to keep warm, it should not be eaten immediately. Let the rice stew for another 15 minutes, and then loosen the rice with a spoon to make it softer and more delicious.
3. Have porridge cooking function.
4. Precautions for heat preservation
  - 4.1 Do not leave the rice spoon or any other sundries in the pot during heat preservation.
  - 4.2 When keeping warm, cover the lid tightly to avoid drying the rice.
  - 4.3 Do not keep cold rice, leftovers or other foods warm with freshly cooked rice.
  - 4.4 Keeping the rice warm for a long time will change color and taste. Therefore, keep the rice warm for no more than 6 hours. The sooner you eat it, the better.

## **Cleaning method**

1. Please boil water when using it for the first time. In the process of boiling water, there may be peculiar smell, which usually disappears after a few minutes. This phenomenon is normal.

2. Take the inner pot out of the rice cooker, wash it with household detergent and rinse it with clear water, and then dry it with a dry soft cloth.

Never scrub the inner pot with a metal brush or other rough washing tools to avoid damage to the inner pot

3. Rice grains or other sundries may be attached to the heating plate. Wear them off with fine sandpaper and clean them with a dry cloth to keep full contact between the inner pan and the heating plate.