








INSTALLATION INSTRUCTIONS

1. Locate the preferred position of the rail on the shower recess wall. Remember to consider both the desired height of your shower head, and also the location of the wall connector, ensuring that the hose can reach the showerhead when it is positioned at the limits of the shower rail.
2. Drill 2 x 6mm holes into the wall at the spacing shown on the installation diagram and insert the wall plugs into the holes ensuring a tight fit, and that the plugs are flush with the wall surface.
3. Slide the bush onto the rail as shown in the diagram. Note: Bush must be installed small end up.
4. Remove the covers from each end of the shower rail by sliding them back at 90° to the rail. Attach the rail to wall by inserting the 2 screws firmly into the wall plugs. Slide the covers back into place.
5. Apply thread tap or other approved sealant to the wall spigot/nipple and then install the connector, ensuring it is tight, flush with the wall, and that the outlet is perpendicular underneath the connector.
6. Fit the hose to the connector ensuring the filter/washer is inserted.
7. Fit the hose to the shower head ensuring both the washer and flow control are inserted according to the diagram. Note: The flow control should be inserted with the protruding side into the showerhead.

Note : The flow control should be inserted with the protruding side into the showerhead, taking care not to cause any damage to the flow controller. In accordance with AS/NZS3662 Cl.6e.

These showers may not be suitable for use with gravity fed water heaters, low and unequal pressure supply networks, instantaneous water heaters, tempering valves and/or thermostatic mixing valves. In accordance with AS/NZS3662Cl.6c.

The following pressure range should be complied with:

- Minimum working pressure 150Kpa
- Maximum working pressure 750Kpa

All ABEY SHOWERS MUST BE INSTALLED IN ACCORDANCE WITH AS/NZS3500 SERIES.

Cerified in accordance with AS/NZS 3662, Licence number WM-022570