



Where the block wall set out does not suit the HiBond module a gap of up to 200mm can be formed using the following methods:

- Use a timber formwork
- Use a sheet metal flashing ex 1.15mm Z275 G250. Fix to the HiBond sheet with 10g-16x16mm Tek screws at 350mm centres. Fix to the block wall with masonry nails with washers at 350mm centres. Full length support will be required if the above fixings is not achieved or if a flat soffit is required.

Original Size A4

Issue: 01	Reference dim_drv_h80_1130
Scale: 1 : 5	
Date: 18 March 2019	